



STR-H711 BOARD HEADER ASSIGNMENTS

EXT1			EXT2			
P0.1	1	0	P0.0	GND	38 39	nRST
P0.3	3	2	P0.2	5V-USB	36 37	3.3V
P0.5	5	4	P0.4	BOOTEN	34 35	STB
P0.7	7	6	P0.6	V1.8BKP	32 33	1.8V
P0.9	9	8	P0.8	P1.14	30 31	P1.15
P0.11	11	10	P0.10	DN	28 29	CLK
P0.13	13	12	P0.12	P1.10	26 27	DP
P0.15	15	14	P0.14	P1.8	24 25	P1.9
P1.1	17	16	P1.0	P1.6	22 23	P1.7
P1.3	19	18	P1.2	P1.4	20 21	P1.5

The pin numbers are printed on the top silkscreen, the above drawings are with TOP view of the board

The distance between the headers is 1"