



## OLIMEX TMS320-XDS100V3, hardware revision C DEBUG HEADER LAYOUTS

ARM\_JTAG\_E:

Close ARM\_JTAG\_E when using ARM\_JTAG connector

Open ARM\_JTAG\_E when using TI\_JTAG\_14 or TI\_JTAG\_20